

Swissmex sprayers are designed with solvent-specific seals for maximum lifespan. Failure to properly clean the sprayer after each use will result in clogged pumps, hoses, wands, spray guns, and tips. It is recommended to rinse the sprayer with the solvent for which it has been designed.

RECOMMENDED CLEANING SOLVENTS FOR EACH SPRAYER TYPE

- Solvent Sprayers – Xylol, Xylene, or Toluene
- Acetone Sprayers – Acetone
- Acid Sprayers – Soapy water

STEPS FOR CLEANING

1. Release tank pressure with the pressure release valve at the top of the sprayer. DO NOT unscrew pump until pressure is released.
2. Pour remaining materials from sprayer tank into suitable storage container.
3. Remove nozzle, tip, spray wand and gun, dispensing remaining materials into suitable storage container.
4. Pour approximately 1 quart of appropriate solvent or cleaner into sprayer tank and shake to rinse. To prevent damage, avoid using solvents not recommended for the sprayer.
5. To clean nozzle and tip, pressurize sprayer and dispense cleaning solvent for 4 seconds into suitable container.
6. To clean wand or spray gun, remove tip and nozzle, then dispense remaining solvent into a suitable container. Properly dispose of cleaning solvent.
7. Re-install nozzle and tip.
8. Wipe down the exterior of the sprayer tank, wand, and host using the cleaning solvent.
9. Inspect the tank, hose, wand, and spray gun for damage, replacing as necessary.



CAUTION: KEEP ALL CLEANING SOLVENTS OUT OF THE REACH OF CHILDREN.

Protective clothing should be worn when cleaning sprayers to avoid irritation to skin and eyes. Cleaning solvents are flammable; avoid sources of ignition. Keep areas ventilated to prevent the accumulation of vapors. **Inhalation:** Use NIOSH approved respirator for organic vapors. **Skin Contact:** Skin contact may cause irritation. Remove contaminated clothing and wash affected skin with soap and water. Launder clothing before reuse. If symptoms persist seek medical attention. **Eyes:** Wear safety eye protection when cleaning. If contact occurs, flush eyes with water for 15 minutes; seek medical attention

